



Eddie Bauer® Highpoint Fleece Jacket. EB240

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest Width	19	20 1/2	22	23 1/2	25	26 1/2	28 1/2	30 1/2
Body Length at Back	27 1/4	28 1/4	29 3/8	30 1/2	31 5/8	32 3/4	33 3/8	34
Sleeve Length	34 3/4	35 1/2	36 1/4	37	37 3/4	38 1/2	39 1/4	40

CHEST WIDTH

Measured across the chest one inch below armhole when laid flat.

BODY LENGTH AT BACK

Measured from high point shoulder to finished hem at back.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.